

## INSTRUCTIONS FOR INSTALLATION OF ACI PART

# AWF 760

### IMPORTANT NOTICE

**READ ALL INSTRUCTIONS PRIOR TO INSTALLATION!  
FIBERGLASS PARTS MUST BE FITTED BEFORE ANY PREP OR PAINT  
WORK!**

THE FOLLOWING INSTRUCTIONS WITH CORRESPONDING PICTURES WILL HELP WITH THE INSTALLATION OF THE PART NUMBER LISTED. IF YOU NEED TECHNICAL ASSISTANCE CALL AMERICAN CUSTOM INDUSTRIES BETWEEN 8:00 AM AND 3:00PM. **1 800 822-8020**

1. REMOVE THE CENTER TWO TAILLIGHT ASSEMBLIES. SET ASIDE TO BE REINSTALLED LATER.
2. REACHING THRU TAILLIGHT OPENING IN REAR BUMPER, LOCATE THE WIRING HARNESS FOR THIRD BRAKE LIGHT AND UNPLUG HARNESS FROM LIGHT.
3. AGAIN REACHING THRU THE TAILLIGHT OPENINGS, LOCATE THE FOUR BRAKE LIGHT HOUSING MOUNTING STUDS. REMOVE THE FOUR RETAINING NUTS AND REMOVE THE BRAKE LIGHT SPOILER ASSEMBLY FROM CAR.
4. WITH THE FACTORY BRAKE LIGHT ASSEMBLY ON THE BENCH, TRANSFER THE FACTORY BRAKE LIGHT TO YOUR NEW ACI SPOILER USING THE TWO SCREWS SUPPLIED WITH SPOILER. ALSO TRANSFER TWO OF THE FACTORY MOUNTING STUDS TO YOUR NEW ACI SPOILER. **(FIG.1)**
5. **NOTE:** SOME LIGHT SANDING MAY BE NECESSARY TO ACHIEVE PROPER FIT BETWEEN BRAKE LIGHT AND SPOILER. **CAUTION: DO NOT OVER TIGHTEN SCREWS.** **(NOTE: DO NOT INSTALL THE TWO SIDED TAPE AT THIS TIME.)**
6. PLACE YOUR NEW ACI SPOILER IN POSITION AND CHECK FOR FIT. MAKE ANY NECESSARY ADJUSTMENTS TO ACHIEVE PROPER FIT.
7. THE SPOILER CAN NOW BE REMOVED. ALSO, REMOVE THE BRAKE LIGHT FROM THE SPOILER AND BEGIN THE PREPPING AND PAINTING PROCESS.
8. ONCE PAINTED YOU CAN INSTALL THE TWO SIDED TAPE TO THE UNDERSIDE OF THE SPOILER. **(FIG.2)**  
**NOTE:** MAKE SURE THE SURFACE OF THE SPOILER AND THE CAR IS CLEAN AND WAX FREE TO ENSURE PROPER ADHESION.

**NOTE: ONLY PEEL BACK ABOUT 2 INCHES OF THE PROTECTIVE COATING FROM THE TAPE AT THIS TIME. (FIG.3)**

9. USING THE INSTRUCTIONS AS A GUIDE REINSTALL THE BRAKE LIGHT TO THE SPOILER. SET SPOILER INTO PLACE AND TIGHTEN THE TWO FACTORY RETAINING NUTS (REMOVED IN STEP 3).
10. ONCE TIGHTENED, APPLY SLIGHT PRESSURE TO THE CORNERS OF THE SPOILER AS YOU NOW REMOVE THE PROTECTIVE COATING FROM THE TAPE. (FIG.4)
11. RECONNECT THE WIRING HARNESS TO THE BRAKE LIGHT AND REINSTALL YOUR TAILLIGHTS.
12. YOU HAVE NOW COMPLETED INSTALLATION OF YOUR ACI SPOILER.

