



INSTALLATION INSTRUCTIONS FOR ACI
75-82 REAR SKIRTS
BGK100, EGK100

IMPORTANT!
READ INSTRUCTIONS BEFORE BEGINNING INSTALLATION

THE FOLLOWING INSTRUCTIONS ARE INTENDED TO FACILITATE THE INSTALLATION OF THE PART NUMBER LISTED. YOU MAY CALL AMERICAN CUSTOM INDUSTRIES FOR TECHNICAL ADVICE, 8:00AM TO 5:00PM EASTERN, SHOULD YOU NEED ASSISTANCE AT 1-800-822-8020.

1. TAPE OFF THE BODY AND BUMPER WHERE SKIRTS WILL BE LOCATED.
2. PRE-DRILL SCREW LOCATIONS ON INSIDE FLANGE OF SKIRTS. THESE AREAS ARE INDENTED TO HOLD THE "J CLIPS".
3. MARK HOLE LOCATION ON THE FACE OF SKIRT.
4. FIT SKIRT IN PLACE. SANDING THE SKIRT ON THE FLANGE AND/OR ON THE INSIDE RADII MAY BE NECESSARY TO ACHIEVE PROPER FIT.
5. ONCE FIT IS SATISFACTORY, DRAW A LINE ON THE TAPE AROUND THE TOP EDGE OF SKIRTS, AND TRANSFER HOLE LOCATIONS FROM FRONT EDGE OF SKIRT TO THE TAPE.
6. MEASURE FROM TOP EDGE OF SKIRT TO CENTER OF PREDRILLED HOLE IN THE FLANGE AND TRANSFER THIS MEASUREMENT TO THE TAPE.
7. DOUBLE CHECK ALL MEASUREMENTS, THEN DRILL HOLES IN THE QUARTER PANELS AND BUMPER USING A 3/16" DRILL BIT.
8. INSTALL "J CLIPS" ON SKIRTS AND MOUNT SKIRTS IN PLACE. ACCESS HOLES FROM UNDER CAR.
9. CHECK AGAIN FOR PROPER FIT, AND MAKE ANY NECESSARY ADJUSTMENTS BEFORE REMOVING TO COMPLETE PAINT WORK.