



INSTALLATION INSTRUCTIONS FOR ACI
80 – 82 COLLECTOR WING
BWF010

IMPORTANT!
READ INSTRUCTIONS BEFORE BEGINNING INSTALLATION

THE FOLLOWING INSTRUCTIONS ARE INTENDED TO FACILITATE THE INSTALLATION OF THE PART NUMBER LISTED. YOU MAY CALL AMERICAN CUSTOM INDUSTRIES FOR TECHNICAL ADVICE, 8:00AM TO 5:00PM EASTERN, SHOULD YOU NEED ASSISTANCE AT 1-800-822-8020.

1. USING 2" MASKING TAPE, TAPE OFF CAR WHERE WING FEET WILL SIT. **NOTE... THIS IS TO PROTECT THE PAINT DURING THE FITTING PROCESS.**
2. PLACE WING ON CAR, CENTERING ON REAR DECK AND MAKING SURE WING IS BACK TIGHT AGAINST THE BUMPER.
3. USING A GREASE PENCIL, TRACE THE FEET OF THE WING ONTO THE MASKING TAPE. FLIP WING UPSIDE DOWN AND TRANSFER MOUNTING HOLE AND AIR VENT HOLE LOCATIONS TO MASKING TAPE. **TIP... YOU MAY ALSO MAKE A TEMPLATE BY PLACING THE WING ON A PIECE OF PAPER OR CARDBOARD, TRACING THE FEET AND CUTTING THEM OUT, REPLACING IT BACK ONTO THE WING FOOT, AND POKING HOLES THROUGH THE TEMPLATE AND INTO THE MOUNTING AND AIR VENT HOLES ON EACH WING FOOT.**
4. ONCE ALL SIX (6) HOLE LOCATIONS ARE MARKED ON CAR, DOUBLE CHECK YOUR MEASUREMENTS AND DRILL USING A 5/16" DRILL BIT.
5. ONCE ALL HOLES ARE DRILLED, TEST FIT WING TO CAR. MOUNTING BOLTS CAN BE INSTALLED BY REACHING FROM UNDER CAR. THE MOUNTING HARDWARE IS A 1" BOLT AND A WASHER FOR EACH FRONT MOUNT AND A 1 ¼" BOLT AND A WASHER FOR EACH REAR MOUNT. MAKE ANY NECESSARY ADJUSTMENTS TO ACHIEVE A SATISFACTORY FIT BEFORE PROCEEDING TO THE NEXT STEP.
6. ONCE YOU ARE SATISFIED WITH THE FIT, REMOVE WING AND COMPLETE ALL NECESSARY PREP AND PAINT WORK.

!!!NOTE!!!

BEFORE PREP SANDING BEGINS, WASH PART DOWN WITH A STRONG DETERGENT, SUCH AS DISH SOAP, TO REMOVE ANY MOLD RELEASE AGENTS PRESENT FROM THE MANUFACTURING PROCESS.

7. ONCE PAINT WORK IS COMPLETE, REINSTALL WING USING CAUTION NOT TO OVERTIGHTEN BOLTS.